


# Akko 3068 Bluetooth Mode Guide



## ■ 1. Switch to Bluetooth mode

Long press FN+TAB, then the TAB signal light should turn off, meaning the keyboard has exited the wired mode;  
Then the signal light of the Caps Lock key should blink and the keyboard will enter the bluetooth mode.

## ■ 2. Select the bluetooth profile

The keyboard can memorize 3 switchable bluetooth devices, which save in FN+E/R/T;  
When you first use the keyboard to match, Bluetooth 1 (FN+E) will be the default profile;  
You can press FN+E/R/T to select the other bluetooth profile to match the Bluetooth devices;  
Once it has been setup and paired, whenever you use the keyboard again, it would memorize the last Bluetooth device it has been worked on, trying to send Bluetooth signal to communicate with that specific device.

## 3. Bluetooth devices

When you use your PC/ PAD/iPhone to pair with the keyboard, and the bluetooth mode of the keyboard and PC/PAD/iPhone have all been turned on, the keyboard would show up with 3 bluetooth profile for each device:

Akko 3068-BT1

Akko 3068-BT2

Akko 3068-BT3

## 4. Switch the bluetooth profile

After those devices have been paired with the keyboard, long press FN+E/FN+R/FN+T for at least 3 seconds to quickly switch between them.

## 5. Shut off the keyboard

You can turn off the back power switch of the keyboard while it is unused to save battery;  
If the keyboard remains unused for over 10 mins, it would go to sleep mode and you can activate it by pressing any key;  
If you are using Windows and the battery save mode for the system has been turned on, it would affect/delay the sleep activation time of the keyboard.

## ■ 6. Reset the keyboard

If you forgot the specific paired front-end device or if the Bluetooth has been in disorder, you can press FN+~ to reset the existing Bluetooth profile of the keyboard.